


兼用ボタンの回路はすべてC型20Aです。




シロトリ
 〒154東京都世田谷区太子堂4-1-1
 PHONE 03-5432-1522
 FAX 03-5432-1529

回路図 1 (平面)

縮尺 1:100

